

## INSTRUCTIONS FOR USE HIT PRO/HIT



## Thank you

Thank you for choosing our product as your means to better hearing.

To support your efforts, we have put great care and attention into making sure that your new hearing instruments are of the highest quality and that they are easy to use and maintain.

We recommend that you read this manual carefully to achieve the maximum benefit of your new hearing instruments.

Congratulations on your decision to actively improve your hearing with today's most advanced hearing technology in the market.

## Contents


Instrument View BTE – 312	5a
Instrument View BTE – 13	5b
Instrument View BTE – Power	5c
Instrument View BTE with Corda <sup>2</sup>	5d
Warnings	
Changing batteries	7
Turning your instrument ON and OFF	9
Left/Right ear marking	10
Putting on your instrument with earmould	11
Putting on your hearing instruments with a Corda <sup>2</sup> (thin tube)	12
Push-button	13
Programs (Optional)	15
Volume Control (Optional)	17
Stand-by (Optional)	18
Tamper-resistant battery door (Optional) BTE 312	21a
Tamper-resistant battery door (Optional) BTE 13 and BTE Power	21b
Telecoil (Optional)	23
Auto Phone (Optional)	24
DAI (Direct Audio Input)	26

FM	28
Caring for your hearing instrument	30
How to change Corda <sup>2</sup> (thin tube)	35
Cleaning your hearing instrument with Corda <sup>2</sup> (thin tube)	36
Daily maintenance with Corda <sup>2</sup> (thin tube) Domes	37
Changing the Corda <sup>2</sup> Dome	38
Avoiding heat, humidity and chemicals	40
Seven easy steps to better hearing	41
Common problems and their solutions	46

### IMPORTANT NOTICE


Please familiarise yourself with the entire contents of this booklet before using your hearing instruments. It contains instructions and important information about the use and handling of your hearing instruments and batteries.

## Instrument View BTE – 312



Battery size: 312


## Instrument View BTE – 13



Battery size: 13

5b

## Instrument View BTE – Power




Battery size: 13




## Instrument View BTE with Corda<sup>2</sup>

Not available for BTE Power

### Your ear piece:



### Open dome:



5d

## **Warnings**

You should familiarise yourself fully with the following general warnings and the entire contents of this booklet before using your hearing instrument.

Hearing instruments and batteries can be dangerous if swallowed or used improperly. Such actions can result in severe injury, permanent hearing loss, or can even be fatal.

- Hearing instruments, their parts, and batteries are not toys and should be kept out of reach of children and anyone who might swallow these items or otherwise cause injury to themselves.
- Never change the battery or adjust the controls of the hearing instruments in front of infants, small children or people with learning difficulties.
- Discard batteries carefully in a place where infants, small children or people with learning difficulties cannot reach them.
- Batteries have occasionally been mistaken for pills. Therefore check your medicine carefully before swallowing any pills.
- Never put your hearing instrument or batteries in your mouth for any reason, as they are slippery and could be swallowed by accident.

## Warnings

- Most hearing instruments can be supplied with a tamper-resistant battery compartment upon request. This is strongly recommended for infants, small children, and people with learning difficulties.

*If a battery or hearing instrument is swallowed, see a doctor immediately.*

### **Usage of hearing instruments**

- Hearing instruments should be used only as directed and adjusted by your Hearing Care Professional. Misuse can result in sudden and permanent hearing loss.
- Never allow others to wear your hearing instrument as incorrect/wrongful usage could cause permanent damage to their hearing.

### **Battery use**

- Always use batteries recommended by your Hearing Care Professional. Batteries of low quality may leak and cause bodily harm.
- Never attempt to recharge your batteries. They may explode and cause serious injury.
- Never dispose of batteries by burning them. There is a risk that they will explode and cause serious injury.

## Warnings

### **Dysfunction in hearing instruments**

- Hearing instruments may stop functioning, for instance if the batteries have expired or if the tubing is blocked by moisture or earwax. You should be aware of this possibility, in particular when you are in traffic or otherwise dependent on warning sounds.

### **Interference**

- Your hearing instrument has been thoroughly tested for interference, according to the most stringent international standards. But new technical developments constantly bring new products into society, and some may emit electromagnetic radiation, leading to unforeseen interference in hearing instruments. Examples include induction cooking appliances, shop alarm systems, mobile telephones, fax machines, personal computer devices, X-rays, Computer tomography etc.
- Your hearing instruments are designed to comply with the most stringent Standards of International Electromagnetic Compatibility. However, your hearing instrument may cause interference with other medical devices. Such interference can also be caused by radio signals, power line disturbances, airport metal detectors, electromagnetic fields from other medical devices and electrostatic discharges.



## Warnings

### Possible side effects

- Hearing instruments may cause an accelerated accumulation of cerumen (ear wax).
- The otherwise non-allergenic materials used in hearing instruments may in rare cases cause a skin irritation.

*Consult a doctor if you experience any of these side effects.*

### Safety requirements regarding Direct Audio Input (DAI)

- The safety of hearing instruments with DAI (Direct Audio Input) is determined by the external signal source. When the DAI is connected to mains-operated equipment, this equipment must comply with IEC-60065, IEC-60601 or equivalent safety standards.

### Warning to hearing instrument dispenser and user

- Special care should be exercised in selecting, fitting and using a hearing instrument where maximum sound pressure capability exceeds 132 dB SPL (IEC 711) as there may be risk of impairing the remaining hearing of the hearing instrument user.

## Changing batteries



The correct battery size appears in the “Instrument View” in the first section of this document.

A worn out battery should be removed immediately and disposed of according to local regulations.

When the battery power is low, you will hear 2 beeps. This pre-warning starts when the battery has only a few hours of operation left. The pre-warning will be repeated in moderate intervals to indicate it is time to change the battery.

If the battery runs out the instrument turns off. When that happens, 4 beeps are played to indicate that the instrument is no longer operating.


This is not an indication of a malfunction.



To replace the battery, follow these instructions:

- Open the battery door completely by pushing the raised edge on the bottom of the instrument. To assist with the handling of the batteries, the magnet placed at the end of the MultiTool can be used.
- Remove the sticky label from the + side of the new battery.
- The new battery may be inserted by using the magnetic end of the MultiTool. Ensure that the positive (+) marking faces the positive (+) sign printed on the battery door. Close the battery door.

If any moisture on the battery surface, it should be wiped off before use. When you change the battery, it will take a few seconds before the battery works to full capacity.



## Turning your instrument ON and OFF


Turn **ON** your hearing instrument by closing the battery door completely with the battery in place. When the battery door is closed the instrument will start up by playing a jingle. This indicates that the battery is working and the instrument is operating.

Turn **OFF** your hearing instrument by opening the battery door slightly until a “click” is felt.

To preserve the battery, make sure your hearing instrument is switched off when you are not wearing it.

### IMPORTANT NOTICE

Open the battery compartment fully to allow air to circulate whenever you are not using your hearing instrument, especially at night!




## Left/Right ear marking

Hearing instruments are fitted to the uniqueness of each ear, which means if you have two instruments then your left hearing instrument is programmed differently from your right. That is why it is important to distinguish between the left hearing instrument and the right.

In order to easily identify whether it is the left ear or right ear instrument, colour markings may be applied inside the battery door.

A blue dot marks the LEFT instrument.  
A red dot marks the RIGHT instrument.




## Putting on your instrument with earmould

Place the tip of the earmould in your ear canal, twisting slightly, making sure that the top part of the earmould (A) is pushed behind and under the fold (B) of your ear.

Gently pull up your ear and press the earmould in the direction of the ear canal.

With the earmould positioned correctly in your ear, place the hearing instrument behind your ear by lifting its lower part and sliding it over the top of your ear.






## Putting on your hearing instruments with a Corda<sup>2</sup> (thin tube)

Not available for BTE Power

Putting on your hearing instrument with a thin tube correctly every time, takes practice:


1. Place the hearing instrument behind your ear.
2. Hold the bend of the tube between your thumb and index finger. The dome should point towards the ear canal opening. Gently push the dome into your ear canal until the sound tube sits close against the side of your head.
3. Position the ear grip in concha using your index finger. Look in a mirror. If the sound tube is sticking out from your ear, the dome has not been placed correctly in the ear canal. If the ear grip is visibly sticking out from your ear it has not been positioned correctly. To remove the instrument pull the bend of the tube.



## Push-button

Your hearing instrument has an ergonomic designed push-button for volume adjustment and switching between different programs.

The push-button can be activated by pressing either the upper part (UP) or the lower part (DOWN).



The push-button on your hearing instrument can be programmed to one of 3 functionalities.

Left	Right	
		<b>Programme shift:</b> Press shortly to change programme.
		<b>Volume control:</b> Press shortly to adjust the volume.
		<b>Both volume control and programme shift:</b> Press shortly to adjust the volume and press long (about 2 seconds) to shift programme.





*To be filled out by your Hearing Care Professional!*

## Programs (Optional)



Your hearing instrument can have up to 4 different programs.

When switching between the different programs, your hearing instrument will beep. The number of beeps will indicate which programme you are using.

	One beep, when you switch to programme 1
	Two beeps, when you switch to programme 2
	Three beeps, when you switch to programme 3
	Four beeps, when you switch to programme 4

Press the upper part to go forwards in the programme cycle e.g from P1-P2.

Press the lower part to go backwards in the programme cycle e.g from P3-P2.

Below you can see a description of the programs available in your hearing instrument.


Prg. 1: \_\_\_\_\_

Prg. 2: \_\_\_\_\_

Prg. 3: \_\_\_\_\_

Prg. 4: \_\_\_\_\_

*To be filled out by your Hearing Care Professional!*



## Volume Control (Optional)



A volume control may be activated.

The volume control allows you to adjust the volume in specific listening situations to the level you feel comfortable with.

To **increase volume**, shortly press the upper part of the push-button.

To **decrease volume**, shortly press the lower part of the push-button.

You will hear a beep when you increase or decrease the volume.

When the hearing instrument is turned on, it starts up at a preferred volume level. When adjusting the volume control to the preferred level, this is indicated by two short beeps.

## Stand-by (Optional)




Push the button for a minimum of 3 seconds to set the instrument in stand-by mode.

To reactivate the instrument, push the button briefly again.

Use the stand-by function if you need to silence the instrument while you have the instrument on.

*Note: pushing either side of the button will set the instrument on stand-by.*



### **IMPORTANT NOTICE**

Do not use the stand-by function as a switch off as the hearing aid still draws power from the battery in this mode.

## Tamper-resistant battery door (Optional) BTE 312



This is strongly recommended for infants, small children and people with learning difficulties.

### Instructions




To lock the battery door:

Make sure the door is completely closed. Use the screwdriver in the MultiTool to turn the tamper-resistant screw to the locked position.

To unlock the battery door:

Use the screwdriver in the MultiTool to turn the tamper-resistant screw to the unlocked position. The battery door can be opened as usual.

*Important: Do not force the battery door beyond its fully opened position. Insert the battery correctly. Excessive force can deform the battery door, which will reduce its tamper resistant effectiveness.*






## Tamper-resistant battery door (Optional) BTE 13 and BTE Power



This is strongly recommended for infants, small children and people with learning difficulties.

The battery door is designed only to be opened by using a tool. Use the MultiTool to unlock the door by inserting it into the channel in the bottom of the hearing instrument and push on the door to open.

*Important: Do not force the battery door beyond its fully opened position. Insert the battery correctly. Excessive force can deform the battery door, which will reduce its tamper resistant effectiveness.*



## Telecoil (Optional)



The telecoil is a receiver for audio signals transmitted from an inductive loop installation. The telecoil is meant for telephone conversations and for loop systems in e.g. theatres, churches or lecture rooms.

The telecoil is activated by the push-button as switching between programs. When activated, you will hear a certain number of beeps corresponding to the telecoil programme.


See “Programs” for where the telecoil programme is placed.

## Auto Phone (Optional)

Your hearing instrument may have a built-in Auto Phone functionality. When the hearing instrument is close to a telephone receiver, the Auto Phone will activate a Phone Programme. When the Phone Programme is activated you will hear a number of beeps.

When you end your telephone conversation, the hearing instrument will automatically return to the previous programme.

Not all telephones can activate the Auto Phone. The telephone receiver must have a special magnet fitted. Please follow the separate instructions for mounting the magnet, which is available from your Hearing Care Professional.



## WARNING

If you use an Auto Phone magnet:

- Keep magnets out of reach of children and pets. If a magnet is swallowed, see a doctor immediately.
- Do not wear the magnet in a breast pocket and always keep it 30 cm away from active implantable devices. Preferably, use the telephone with magnet on the opposite side than a pacemaker or other active implantable devices.
- Keep the magnet 30 cm away from credit cards and other magnetically sensitive devices.

## DAI (Direct Audio Input)


If your hearing instrument is connected by means of a DAI adaptor with an external sound source, like a media player/MP3 or hand mic, the signals of these devices will be directly transferred to your hearing instrument.

### Mounting of the DAI adaptor

Start by opening the battery door, slide the DAI adaptor onto the instrument.

Then insert the DAI cord into the adaptor.

When the DAI adaptor is connected, the instrument will automatically switch to a combination of a DAI programme and the microphone input of the instrument.



If you would like the DAI programme alone, you can switch to the next programme by using the programme switch button.

As long as the DAI adaptor is connected to the instrument two programs will automatically be added after the standard programs, which have been programmed into your hearing instrument by your Hearing Care Professional.

### IMPORTANT NOTICE

When the DAI is connected to mains-operated equipment, this equipment must comply with IEC-60065, IEC-60601 or equivalent safety standards.

## FM


An FM receiver enables the hearing instrument to receive signals directly from an external wireless FM transmitter.

### Mounting of the FM receiver

Start by opening the battery door. Slide the FM receiver onto the instrument.

As long as the FM receiver is connected to the instrument two FM programs will automatically be added after the standard programs, which have been programmed into your instrument by your Hearing Care Professional.


When the FM receiver is connected and turned on, the instrument will automatically switch to a programme that receives signals from the microphone in combination with an external wireless FM transmitter.



If you would like to receive input from the FM transmitter alone, you can switch forwards to the next FM programme by using the programme switch button.

With the FM receiver mounted, the push button of the hearing instrument can at any time be used to switch back and forth between standard programs and FM programs.

For detailed instructions on handling and use of the FM receiver, refer directly to the dedicated receiver guide.



## Caring for your hearing instrument

Your ear canal produces ear wax (cerumen) which may clog up the sound outlet or the ventilation opening of your ear mould. To prevent wax accumulation causing a change in performance, the guidelines in this section should be followed.


When handling a hearing instrument, keep it over a soft surface to avoid damage if you drop it.

### Before retiring at night:

- Make sure that there is no ear wax in any of the earmould openings since it may reduce the hearing instrument's efficiency.
- Open the battery door to allow air to circulate.

## Cleaning the instrument

The multi-purpose tool contains a brush for the special purpose of cleaning your instruments. This should be used to ensure the best care and performance of your hearing instruments.




### Cleaning the earmould

- Clean away any traces of wax from around the sound outlet with the brush.
- Clean the ventilation opening by pressing the brush through the hole while twisting it slightly.

Use the cloth to clean the surface of the instrument.

Replace the brush when necessary. Just pull it out of the handle and insert a new fresh brush. Press the new one firmly into the handle.




Brushes can be purchased from your Hearing Care Professional.




### Washing the earmoulds

The earmoulds should be washed regularly:

- Disconnect the earmould and the tubing from the sound hook of the hearing instrument.
- Wash the earmould in lukewarm water using a mild soap. Do not use strong detergents.
- Rinse with water.
- Dry the earmould.
- Any water drops inside the earmould or tubing should be blown out. A special device for this purpose (an earmould blower) is available from your Hearing Care Professional.



- Make sure the earmould and tubing are completely dry before they are reconnected to the hearing instrument. Be careful that left ear earmould and tubing are connected to the hearing instrument with left ear marking and vice versa for the right ear instrument.



### Replacing the tubing




The tubing in the earmould should be replaced when it becomes yellow or stiff. Consult your Hearing Care Professional in relation to this.

### IMPORTANT NOTICE

The hearing instrument itself must **never** be washed or immersed in water or other liquids!

### How to change Corda<sup>2</sup> (thin tube)

1. Pull tube out of the Hearing Instrument
2. Push tube into the Hearing Instrument
3. Correct






## Cleaning your hearing instrument with Corda<sup>2</sup> (thin tube)

### To remove cerumen from the thin tube:

- Pull tube out of the hearing instrument.
- Insert the cleaning tool in the tube all the way through.
- Remove the tool and push the tube into the hearing instrument.




## Daily maintenance with Corda<sup>2</sup> (thin tube) Domes

The dome should not be cleaned. When you require a fresh, clean dome, remove the existing one and put on a fresh one.

We recommend the dome to be replaced at least once a month or as directed by your Hearing Care Professional.

## Changing the Corda<sup>2</sup> Dome

The dome is easy to replace. Hold the widest part of the dome and pull it off from the connections joint on the tube. Place the new dome on the speaker and ensure that it is fastened securely.



### IMPORTANT NOTICE

The dome is made of a soft, medically approved rubber material. If the dome comes off in the ear canal, it will not cause any harm. If you can, carefully take it out. If necessary, let another person help you. Do not push the dome into the ear canal. Do not push the tube into the ear again before the dome is removed from the ear. If you have any doubts, contact your Hearing Care Professional.

### IMPORTANT NOTICE

- Only use parts designed for your hearing instruments.
- The cleaning tools should only be used for cleaning the tubing when it is detached from the hearing instrument and not on the ear.
- The dome must be properly attached to the sound tube before inserting it in your ear.
- If the dome is not correctly attached and falls off in the ear:  
Please see your hearing care professional or seek medical consultation.
- The tube should never be used without a dome attached.
- Proper preventive care and maintenance will go a long way toward ensuring reliability and safe performance. Clean your sound tube on a regular basis.
- Do not share your hearing aids or any of the parts with other people.
- Ensure your hands are clean when handling the hearing instrument and its parts.

## Avoiding heat, humidity and chemicals

Your hearing instrument must never be exposed to extreme heat e.g. left inside a parked car in the sun. They must never be exposed to a lot of moisture e.g. steam baths, showers or heavy rain. Nor must they be dried in microwave ovens or other ovens.

Wipe the batteries carefully if moisture is present as it may affect their performance. Using an anti-humidity kit can help to avoid these problems and may even extend the life of your hearing instrument. Consult your Hearing Care Professional for further advice.

The chemicals in cosmetics, hairspray, perfume, aftershave lotion, suntan lotion and insect repellent can damage your hearing instrument. You should always remove your hearing instrument before applying such products and allow time for the product to dry before refitting your hearing instrument. If you use lotion, be sure to wipe your hands dry before putting on your hearing instrument.

## Seven easy steps to better hearing

It takes time to adjust to a new hearing instrument. How long this adjustment takes differs from person to person. It will depend on a number of factors, such as whether you have had a hearing instrument before and the degree of your hearing loss.

### **1. In the quiet of your home**

Try to accustom yourself to all the new sounds. Listen to the many background sounds and try to identify each sound. Bear in mind that some sounds will seem different from what you are used to. You may have to learn to identify them again. Note that in time you will get accustomed to the sounds in your environment – if not please contact your Hearing Care Professional.

If using the hearing instruments makes you tired, take them off for a little while and have a rest. Gradually, you will begin to be able to listen for longer periods of time. Soon, you will be able to wear your hearing instruments comfortably all day long.

## **2. Conversation with another person**

Sit with someone else in a quiet room. Face each other so you can read facial expressions easily. You may experience new speech sounds, which can seem a little disturbing in the beginning. However, after the brain has adapted to the new speech sounds, you should hear speech clearer.

## **3. Listen to radio or TV**

When listening to the TV or the radio, start out by listening to news commentators since they usually speak clearly, then try other programs.

If you find it difficult to listen to TV or radio, your Hearing Care Professional should be able to give you advice on available accessories to enhance your listening capabilities for TV and radio.

## **4. In group conversations**


Group situations are usually accompanied by a greater degree of background noise, and are, therefore, naturally more difficult to cope with. In such situations, therefore, focus your attention on the person you want to hear. If you miss a word, ask the speaker to repeat.

## **5. Telecoil use in church, theatre or cinema**

An increasing number of churches, theatres and public buildings often have loop systems installed. These systems send out wireless sound to be received by the telecoil in your hearing instrument. Typically, a sign will let you know whether the place has a telecoil. Ask your Hearing Care Professional for details.

## **6. Using the telephone**

When using the telephone, tilt the receiver edge lightly on your cheek-bone and position the phone slightly over the ear close to the hearing instruments microphone. The sound then flows directly into the hearing instruments microphone opening. This way, the hearing instruments will not whistle and you ensure the best conditions to understand the conversation. When you have the receiver in this position, remember to speak directly into the mouthpiece on the telephone in order to ensure good understanding on the other “end of the line”.



All BTE hearing aids have a telecoil built in, if your telephone has a built in tele-loop, you can switch into telecoil programme in order to improve the sound reception further.

Remember that the telecoil in your hearing instruments may pick up disturbing signals from electronic devices, such as fax machines, computers, televisions or similar. Make sure that the hearing instrument has a distance of 2 – 3 meters to such devices when using the telecoil programme.

#### **7. Wireless and mobile phones**

Your hearing instrument is designed to comply with the most stringent Standards of International Electromagnetic Compatibility. However not all mobile phones are hearing instrument compatible. The varying degree of disturbance can be due to the nature of your particular mobile phone.

If you find it difficult to obtain a good result while using your mobile telephone, your Hearing Care Professional should be able to give you advice on available accessories to enhance listening capabilities.

#### **Use your hearing instruments all day long**

The best way to ensure better hearing is to practice listening until you can wear your hearing instruments comfortably all day. In most cases, you will not get the full benefit of the hearing instruments if you use them infrequently.

Your hearing instruments will not restore normal hearing. Nor will they prevent or improve a hearing impairment resulting from a physiological condition. What they will give you, however, is help towards making better use of the hearing ability that you have. If you have two hearing instruments always wear both.

#### **The most important benefits of wearing two hearing instruments are:**

- Your ability to localize sounds will improve.
- It will be easier to understand speech in noisy surroundings.
- You will experience a fuller, more comfortable sound picture.

<b>Common problems and their solutions</b>		
<b>Symptom</b>	<b>Possible causes</b>	<b>Solutions</b>
<b>No sound</b>	Worn-out battery	Change battery <span style="float: right;">pg. 7</span>
	Clogged sound outlet	Clean earmould <span style="float: right;">pg. 32 &amp; 36</span>
<b>Intermittent or reduced sound</b>	Clogged sound outlet	Clean earmould <span style="float: right;">pg. 32 &amp; 36</span>
	Moisture	Wipe battery and instrument with dry cloth <span style="float: right;">pg. 40</span>
	Worn-out battery	Change battery <span style="float: right;">pg. 7</span>
	Clogged damping filter in hook	Contact your Hearing Care Professional for assistance
<b>Squealing noise</b>	Hearing instrument inserted improperly	Reinsert hearing instrument <span style="float: right;">pg. 11</span>
	Ear wax accumulated in ear canal	Have ear canal examined by your doctor

*If none of the above solutions solves the problem, ask your Hearing Care Professional for assistance.*

## **International Warranty**

Your hearing instruments are covered by a limited warranty issued by the manufacturer for a period of 12 months from the date of delivery. This limited warranty covers manufacturing and material defects in the hearing instrument itself, but not accessories such as batteries, tubing, earwax filters etc.

Problems arising from improper handling or care, excessive use, accidents, repairs made by an unauthorized party, exposure to corrosive conditions, physical changes in your ear, damage due to foreign objects entering the device, or incorrect adjustments are NOT covered by the limited warranty and may void it.

The above warranty does not affect any legal rights that you might have under applicable national legislation governing sale of consumer goods. Your Hearing Care Professional may have issued a warranty that goes beyond the clauses of this limited warranty. Please consult him/her for further information.

## **If you need service**

Take your hearing instrument to your Hearing Care Professional, who may well be able to sort out minor problems and adjustments on the spot.

## Warranty Certificate

Name of Owner: \_\_\_\_\_

Dispenser: \_\_\_\_\_

Dispenser Address: \_\_\_\_\_

Dispenser Phone: \_\_\_\_\_

Purchase Date: \_\_\_\_\_

Warranty Period: \_\_\_\_\_ Month: \_\_\_\_\_

Model Left: \_\_\_\_\_ Serial no.: \_\_\_\_\_

Model Right: \_\_\_\_\_ Serial no.: \_\_\_\_\_

Battery Size: \_\_\_\_\_

## Product approval, precautions and markings


The hearing instrument contains a radio transmitter using short range magnetic induction technology working at 3.84 MHz. The magnetic field strength of the transmitter is  $< -42 \text{ dB}\mu\text{A/m @ 10m}$ .

The emission power from the radio system is well below international emission limits for human exposure. For comparison, the radiation of the hearing instrument is lower than unintended electromagnetic radiation from for example halogen lamps, computer monitors, dishwashers etc. The hearing instrument complies with international standards concerning Electromagnetic Compatibility.

Due to the limited space available on the instruments all relevant approval markings are found in this document.



The hearing instrument contains a module with:



The device complies with Part 15 of the FCC rules and RSS-210 of Industry Canada.

Operation is subject to the following two conditions:

1. this device may not cause harmful interference.
2. this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

908 68 610 00 / 05.13

Hereby, Oticon A/S declare that this hearing instrument is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.  
Declaration of conformity is available at:

Oticon A/S  
Kongebakken 9  
DK-2765 Smørum  
Denmark  
[www.oticon.com](http://www.oticon.com)

908 68 610 00 / 05.13

**CE 0543 0682**



Waste from electronic equipment must be handled according to local regulations.



NI 175



94802010000001