# Medr<sub>x</sub>. TRAINING MANUAL



*Revolutionary Tinnitus Assessment* 

# $\begin{array}{c} MedRx\\ TINNOMETER\\ \hline \end{array} \\ \hline$

# Contents

Introduction	3
AVANT™ Audiometer Software Overview	4
AVANT <sup>™</sup> Audiometer Software Options	4
Preparing for Testing	8
Pure Tone Audiometry	10
Tinnometer™	11
Printing	23
Limited Warranty	24

## **(E** #0123

TÜV SUD Certificate Body Ridlerstraße 65 ° 80339 Munich ° Germany



## www.medrx-usa.com

1200 Starkey Rd., #105, Largo, FL 33771 U.S.A. Toll Free: (888) 392-1234 • (727) 584-9600 Fax: (727) 584-9602 • Email: medrx@medrx-usa.com

EC REP

MedRx's Authorized Representative in Europe

DGS Diagnostic A/S Audiometer Alle 1 ° 5500 Middelfart ° Denmark

# Introduction

The MedRx Tinnometer represents a new era of ultra-compact screening audiometry for your office. Compact yet rugged, this PC-Based system is USB powered and supports current ANSI and IEC audiometric tests. *This manual assumes that the system hardware, software and drivers are installed and working properly.* Please refer to the MedRx Tinnometer Installation Manual for assistance. The Installation Manual is included in the original Tinnometer packaging in PDF format on the USB Flash Drive.

The scope of this manual is to get you "up and running" with your MedRx Tinnometer. Please consult the interactive Help System within the software for more detailed information of features and functionality. To access this tool, press the F1 key at any time, or click the Help icon or text menu with your mouse. Access these by clicking on the "Help" tab at the top of the screen, and select "Help Topics". Select an item from the list in the Index tab and click "Display".



## **The AVANT Audiometer Software Overview**

The AVANT Audiometer software can run stand-alone or from NOAH<sup>™</sup> System or the TIMS<sup>®</sup> NOAH-Compatible Office System.

## Launching the AVANT Audiometer Software

#### Stand Alone



 Double Click the AVANT Audiometer shortcut on your Windows Desktop. NOAH



- Launch NOAH.
- Launch Avant Audiometer module following NOAH procedures.

## **Basic Software Options**

Several options are available which allow the user to customize the AVANT Audiometer Software to meet their needs.

Access these options from the File Menu on the AVANT Audiometer Main Screen as **shown** below.



The Options may also be accessed from the Audio screen by clicking on the **Options** text menu as shown below.



Options	
View Screening Audiometry MHA	/HLS Tymp
Plot Vertical Grid Vertical Grid Sight Style: Lines Size: 50	Speech Spectrum Canoe Speech Sounds Language: <default> Font Size: 12</default>
Dual Plot Mode	Default Ear: Right 💌
Reverse Ears	Plot Curves Width: Medium 💌
Maintain Plot Ratios	✓ Use Plot Antialiasing
	DK Cancel Help

The **View** tab allows you to set the default appearance of the test environment.

Options	<b>x</b>
View Screening Audiometry MHA/HLS Tymp	1
Arrow Buttons	Default Test:
Move Up by (dB): Move Down by (dB): 10 ÷	Manual 💌
Auto Sound	Auto Screening
	Auto Thresholds
I Enable Operator Headset	Advanced
Enable Talkback Microphone	Transducers
ОК	Cancel Help

The **Screening Audiometry** tab sets the look and behavior of the Tinnometer.

Options	×
View Screening Audiometry MHA/HLS Tymp	
Show The Norm Area Scaling: Auto	
✓ Auto Switch Modes	
Iv Interpolate Curve	
✓ Allow Multiple Records	
	Help

If your system has a **Tympanometer** connected, this tab will assist in configuring the look of the display.

**NOTE:** Remember, more information is always available in the Interactive Help System by clicking the Help Icon or pressing the F1 key.

## **Assign Transducers**

**Option 1:** On the Audiometry Options screen click *Transducers* to assign specific transducers to the audiometer outputs.



**Option 2:** You can change transducers by *Right-Clicking* on any transducer icon on the Screening screen.



The Transducers dialog box will then appear. Select the appropriate transducer for each output.

Transducers		x
Air Conduction: DD45		•
	ОК	Cancel

## **Advanced Options**

1990 A.			
File	Function Help		
Print Setup			
Page Setup			
Clear Session Data			
Options			
Advanced Options			
Ex	ât		

The Advanced Options screen allows you to configure your system to meet your individual clinical needs. It also provides MedRx Technical Support with tools for helping you troubleshoot technical issues. Access this screen from the File Menu on the Avant Main Screen as shown to the right.

The key features of each tab are described below. For more in-depth information, consult the interactive Help system within the software by pressing the F1 key or clicking the Help icon.

Advanced Options	×
General Audio Video Tympanometry	
Multiple Monitors	CD-ROM Drive: D:
Home Directory	Calibration Data
Device Manager Control Panel System Information	Language
	OK Cancel Help

The **General** Tab configures the overall Tinnometer behavior with respect to other Windows programs, specifically NOAH.

Advanced Optio	ins	×
General Audio	Video Tympanometry	
Otoscope In	iput	
Device:		-
	Source Format Adjust	
-		
Alternative I	nput	
Device:		•
	Source Format Adjust	
	OK Cancel	Help

If your system has a Video Otoscope, the *Video* tab allows you to select the appropriate device driver.

General Audio Video Tympanom	netry
Output Device. Speakers (Med	Inx AIR+)
Input Device:	<b>*</b>
Output Mixer: MedRx AIR+	•
Input Mixer:	Ţ
Microphone Gain (dB):	Set Defaults Audio Properties
	OK Cancel Help

Use the **Audio** Tab to select the proper audio device for your Audiometer. This tab also provides access to the Windows Audio controls.



If your system has a **Tympanometer** connected, use this tab to identify it and ensure the driver and software that control it are correctly installed.

## **Preparing for Testing**

Use the accessories provided with your MedRx Tinnometer. Typical acceptable transducers are shown on the "Transducer & Accessories" page in the Installation manual. Operator headsets for use with the MedRx Tinnometer should have 32 ohms impedance and the speaker power should be at least 50 watts. Air conduction transducers for use with this device should have an impedance of 10 ohms. The speaker voltage should match the local mains voltage where the device is used.

The Operator Headset with microphone is used by the device operator to communicate with the patient. The patient talks to the operator using the Talk-Back microphone.

## **Placing the Earphones on the Patient**

### **High Frequency Earphones (DD450)**



1. Place the earphones on the patient's head so the center of the earphone is directly over the opening of the ear canal.

Adjust the headband so the earphones remain in place, but be careful not to make it so tight as to cause patient discomfort.

## **Device Maintenance**

Annual re-calibration of the transducers used with the Avant Audiometer is recommended. There are no user repairable components of this device. Refer to the *Installation Manual* for care and cleaning instructions.

## **Performing Audiometric Testing**

The screen shot below shows the all feature controls which are available on the Audiometer main window. \*Depending on the features that have been enabled, on your device, some icon may not be available.\* The sections of the manual that follow explain how to use these tools to perform hearing evaluations using your MedRx Tinnometer.



- 1. Test selection tool bar
- 2. Ear selection
- 3. Output selector
- 4. Test Type Selector
- 5. Tone Type Selectors
- 6. Output Level Potentiometers
- 7. Masking interrupter and routing selector

- 8. No Response button
- 9. Test Interrupter
- 10. Back
- 11. Help
- 12. Discard
- 13. Talk Over
- 14. Legend

## **Pure Tone Audiometry**

Pure Tone Audiometry measures the patient's peripheral hearing sensitivity, or the softest levels they can hear pure tones at a variety of frequencies. These thresholds are plotted on a standard graph called an audiogram. The AVANT Audiometer software controls the hardware, stores the data (if running within NOAH or TIMS) and prints a standard audiogram report. Pure tone Audiometry can be performed via earphones or a Bone Conductor (Bone Conduction).

#### **Prerequisites:**

• Before performing audiometry, careful inspection of the ear canal should be performed. This is best done with Video Otoscopy. After ensuring the ear canal is clear, place the appropriate transducer on the patient as shown on page 8 & 9.

## **Pure Tone Audiometry via DD450**

#### (High Frequency Supra-Aural Headphones)

- 1. From the main Audiometer Window, Click the menu bar.
- 2. By default, the button will be selected once you enter the main Audiometry Screen. Other default settings (based on typical clinical practice and procedures) are:
  - a. Right Ear
  - b. AC (Air Conduction)
  - c. Tone Stimulus
  - d. Continuous Tone
- 3. Instruct the patient that they will hear several very quiet (soft) tones (beeps) and that they should signal (raise their hand, press the patient response button, etc.) as soon as they hear it. It is helpful to also say "even if it seems very far away".
- 4. Begin at 1000 Hz in the Right ear (unless the patient reports better hearing in the left ear).
- 5. Present a tone at 60 dB by pressing the space bar or clicking the space bar or clicking the
- 6. If the patient does not hear the tone (does not signal), raise the level 5 dB using the up arrow on your keyboard and present again.
- 7. Repeat step 6 until the patient signals that they hear the tone.
- 8. When the patient signals they hear the tone, decrease the level by 10 dB and present the tone again.
- 9. Repeat steps 6 through 8 until the patient responds to a tone at the same level 2 times with the level ascending.

10. Using the right arrow key, change the test frequency to 2000 Hz and repeat steps 5 through 8 to establish the threshold at 2000 Hz.

# **NOTE**: If the threshold at 2000 Hz is more than 20 dB different (less than or greater than) the threshold at 1000 Hz, repeat steps 5 through 8 at 1500 Hz (the "half octave" between 1000 Hz and 2000 Hz).

- 11. Repeat steps 5 through 8 for 4000 Hz, 8000 Hz, 500 Hz and 250 Hz.
- 12. Repeat steps 5 through 11 in the opposite ear.

## **NOTE**: The software automatically calculates the 3-frequency Pure Tone Average (PTA) which is displayed above and inside the legend as follows:



## Tinnometer

#### **Purpose of the Tinnometer**

Tinnitus is experienced by millions of people worldwide. The Tinnometer is designed to mimic the sounds of tinnitus in order to provide an accurate and flexible tinnitus assessment. Tinnitus Assessment increases patient rapport with the clinician when an equivalent tinnitus sound can be created. The Tinnometer can accurately create tinnitus sounds for fast and reliable tinnitus assessment. All test results should be used to help counsel the patient on their specific tinnitus and what the assessment has found.

## The Tinnometer test was developed to:

- 1. Break away from the traditional limitation of tinnitus assessment with an audiometer
- 2. Produce accurate and flexible sounds that mimic patient tinnitus
- 3. Provide extended frequency ranges to more accurately match tinnitus sounds
- 4. Decrease the time needed to complete a tinnitus assessment
- 5. Standardize reporting needed when completing tinnitus assessment
- 6. Allow clinicians to save and recall prior tinnitus assessments
- 7. Provide general guidelines for implementing results into tinnitus sound therapies provided by leading hearing aid manufacturers

## **Performing the Tinnometer Testing:**



• Click the *Tinnometer* button from the main Avant Audiometer main screen.

The following screenshot shows the key features of the Tinnometer:

- 1. Toggle Switch to Start/Stop stimulus
- 2. Sliders to control frequency, bandwidth, slope and tempo of the stimulus
- 3. Slider to control the intensity of the stimulus
- 4. Buttons used in determining tinnitus match, threshold and minimum masking level
- 5. Area where description of items will be displayed
- 6. Channels designed to present multiple types of tinnitus sounds
- 7. A graphical display of the sounds being played for the patient. Stimulus and Audiogram (if done within Avant or Noah) are display in dB SPL



Interactions with the patient are controlled as follows:



- 1. Patient response switch indicator
- 2. Patient monitor microphone
- 3. Talk forward

- 4. Undo
- 5. Toggle help section
- 6. Return to Avant

## There are 3 Steps needed for Tinnitus Assessment with the Tinnometer

- 1. Identify patient's tinnitus by frequency, bandwidth, slope and tempo
- 2. Lower the identified tinnitus until patient threshold is reached
- 3. Raise the tinnitus level above the identified tinnitus intensity (widen bandwidth if needed) until the patient states they no longer hear the tinnitus. Play stimulus for 60 seconds to ensure masking is achieved.

#### Step 1: Identify Patient's Tinnitus



 Start by selecting the *tinnitus type* that has been described by the patient. This is an approximation of the tinnitus sound your patient hears. Tinnitus type will provide a starting frequency, bandwidth and slope to help speed up testing time.



2. Use the stimulus **start/stop toggle** to present the selected signal to the patient.



- Use frequency slider to match the pitch of the patient's perceived tinnitus
- 4. Use volume slider to match patient's perceived intensity of tinnitus
- 5. Adjust bandwidth, slope and tempo (for pulsating tinnitus or prevention of adaptation) as needed
- Buttons to allow greater flexibility in bandwidth and slope of tinnitus. Allows the addition of high/low frequency sounds independently
- 7. Allows for independent right/left volume control
- 8. Press Tinnitus Level button once the patient's tinnitus is matched

#### **Step 2: Find Identified Tinnitus Threshold**



- 1. Use **down** arrow on your keyboard to lower stimulus until patient states they are no longer able to hear the tinnitus.
- 2. Click Threshold Level button.

#### Step 3: Masking Tinnitus for 60 Seconds





 Use volume slider to increase intensity of the stimulus until the patient states they are no longer able to hear their tinnitus.

NOTE: Lower levels of masking may be achieved by increasing bandwidth of the masking stimulus. Pulsating the masking noise can prevent tinnitus adaptation.

- 2. Press the *MML button* and continue presenting stimulus until 60 second countdown ends.
- 3. If patient begins to hear their tinnitus within the 60 seconds, raise intensity until masking is achieved and repeat number 2.

#### **Tinnometer Modulation Tab**

The Tinnometer modulation tab is designed to simulate sound generators when hearing aid demonstrations cannot be performed. The following are controls used in Modulation.



- 1. Type of modulation Sound
- 2. Speed of modulation
- 3. Frequency of modulation

4. Modulation volume range To use the Modulation features within Tinnometer, you must first complete the three steps involved with tinnitus assessment. Once tinnitus assessment is complete, you can use modulation by:

Chanr 66dB	nei 1 🔵 ( 4842.29 Hz	) 66dB
56dB 4SL Re 10SL	Threshold Level elative Tinnitus Level Relative MML	56dB 4SL 10SL
	Low	High
Band in octave	0.15	0.15
slope in %	100	100

1. Activating the channel in which the tinnitus assessment was performed.



2. Enter the modulation tab on the right side of Tinnometer software.

Random		<b></b>
Music		20
Ccean modulatic		۰ <b>ــــــ</b>
		-20
		-40
		-60
		-80
		-100
beed modulation	equency modulati	Level modulation

3. Adjust the modulation stimulus with sliders as a counseling tool for the patient.

#### **Tinnometer Audiometry Scan**

The Tinnometer Scan tab is designed for various forms of air conduction audiometry. There are three types of audiometry that can be performed with Tinnometer. You can access the forms of audiometry with the buttons located by the number 1 in the image below.

Scan	BEKEZY
	Scan
	Audiogram

#### **Tinnometer Residual Inhibition (RI)**

The Tinnometer RI tab is designed for Residual Inhibition (RI) testing for a patient's tinnitus. The controls in the RI tab are as follows:



- 1. Scale from 0-10 of tinnitus bothersome level
- 2. Timer to begin stimulus
- 3. Tracking of patient's tinnitus bothersome level as a function of time

A complete tinnitus assessment must be performed prior to performing testing in the RI tab. Once tinnitus assessment testing is completed, optional residual inhibition testing can be performed with the following steps:

Chanr 66dB	nei 1 🔵 ( 4842.29 Hz	) 66dB
56dB 4SL Re 10SL	Threshold Level elative Tinnitus Level Relative MML	56dB 4SL 10SL
	Low	High
Band	0.15	0.15
slope in %	100	100







1. Activating the channel in which the tinnitus assessment was performed.

2. Select the RI tab on the right side of the Tinnometer software.

- 3. Ask the patient the bothersome level of their tinnitus from 1 to 10 and mark their response.
- Click the stop watch to begin the masking stimulus (stimulus to play for 60 seconds).

5. Stimulus will play for 60 seconds and automatically stop at the 60 second point.



- 6. When the stimulus stops the patient must redefine their tinnitus bothersome level every 30 seconds. The bothersome level should decrease upon the stimulus stopping and will increase with time.
- 7. The test continues until the bothersome level returns to pre-test level.

#### **Tinnometer Report Printing**

The Tinnometer has four reports available for printing: tinnitus assessment report, manufacturer guidance report, questionnaire report and a channel report.

The following are common features found across reports:



1. To generate your report, select "printer ..." from the File menu.







|--|--|--|

- 2. Select the paper style you are printing.
- 3. Confirm all patient information is correct.
- 4. Choose your print preferences.
- 5. Change the zoom of your print preview.
- 6. Print your Report.

#### **Tinnitus Assessment Report**

Tinnitus assessment reports are able to be generated after completing the three steps to tinnitus assessment. Once all steps are complete you are able to print a report

🕕 MedRx -	Speakers (3- US	B Audio Device	) - TinnoMeter	Me
File Outpu	ut Tinnitus type	Questionaire	Information	Lan
New				
Open				
Save				
Manufa	acturer Guidance	•		
Print		• print	er	
Exit				
Channel 1				
All Channel 2	s			
Graph Char	Ouidance			
Graph Char	inel 2			
Graph Char Graph Char	inel 3 inel 4			

 To generate your tinnitus assessment report, select "printer ..." from the File menu.

2. The "Channel" reports are the tinnitus assessment reports. Select the channel used for testing or All Channels when multi-channel testing is completed.

Diagnosis Code	
	-
H93.11 Tinnitus, right ear	
H93.12 Tinnitus, left ear	
H93.13 Tinnitus, bilateral	
H93.19 Tinnitus, unspecified ear	
Comments 4x60 characters	
L	

- 3. Use the drop down box to select a diagnosis for the patient.
- 4. Comments can be entered in 4 separate lines with a maximum of 60 characters.
- 5. Print the Report.

#### **Manufacturer Guidance Report**

Manufacturer guidance reports are designed to provide hearing aid sound therapy guidance to a clinician based on tinnitus assessment results. Sound therapy is an option to tinnitus treatment. We encourage all clinics to develop a tinnitus treatment protocol that is in line with their tinnitus treatment goals. Manufacturer guidance generated by the Tinnometer is designed to be a starting point in sound therapy and each patient may differ in preferred sound.

Manufacturer guidance reports are able to be generated after completing the three steps to tinnitus assessment. Once all three tinnitus assessment steps are complete you are able to print a report.



- 1. Select the manufacturer that you would like to have printed in your report.
- To generate your tinnitus assessment report, select "printer ..." from the File menu.

Channel 1 Channel 2 An Channels Hearing Aid Guidance Graph Channel 2 Graph Channel 3 Graph Channel 4	
Diagnosis Code	

Comments 4x60 characters

H93.19 Tinnitus, unspecified ear

3. Select "Hearing Aid Guidance" from the list of reports.

- 4. Use the drop down box to select a diagnosis for the patient.
- 5. Comments can be entered in 4 separate lines with a maximum of 60 characters.
- 6. Print the report.

#### **Graph Channel Report**

Graph channel reports will print a patient report which displays an image of the patient's tinnitus with QR codes for YouTube videos that play a wind modulation noise nearest to their tinnitus. To generate the report you must:



1. To generate your tinnitus assessment report, select "printer ..." from the File menu.

Channel 1 Channel 2 All Channels	-
Graph Channel 1 Graph Channel 2 Graph Channel 3 Graph Channel 4	

2. Select "Graph Channel" from the list of reports. Select the channel number which you used to match your patient's tinnitus sound.

3. Print the report.

#### **Questionnaire Report**

Questionnaire reports will only show as an option once the questionnaire has been completed. Once a questionnaire has been completed and you are ready to print a report you must:

	/ledRx - Sp	beakers (3- USB	Audio	Device]	) - TinnoMete	r Me
File	Output	Tinnitus type	Questi	onaire	Information	Lan
	New					
	Open			<b>,</b>		
	Save					
	Manufacti	urer Guidance	•			
	Print			print	er	
	Exit					
Cha	nnel 1					
Cha Cha	nnel 1 nnel 2					
Cha Cha All (	nnel 1 nnel 2 Channels					
Cha Cha All ( Hea	nnel 1 nnel 2 Channels ring Aid G	uidance				
Cha Cha All ( Hea Gra	nnel 1 nnel 2 Channels ring Aid G ph Channe	uidance el 1				
Cha Cha All ( Hea Gra Gra Gra	nnel 1 nnel 2 Channels ring Aid G ph Channe ph Channe ph Channe	uidance el 1 el 2 el 3				
Cha Cha All ( Hea Gra Gra Gra	nnel 1 nnel 2 Channels ring Aid G ph Channe ph Channe ph Channe ph Channe	uidance el 1 el 2 el 3				
Cha Cha All ( Hea Gra Gra Gra THI	nnel 1 nnel 2 Channels ring Aid G ph Channe ph Channe ph Channe	uidance el 1 el 2 el 3 el 3				
Cha Cha All ( Hea Gra Gra Gra THI	nnel 1 nnel 2 Channels ring Aid G ph Channe ph Channe ph Channe ph Channe	uidance al 1 al 2 al 3 al 4				
Cha Cha All ( Hea Gra Gra Gra THI	nnel 1 nnel 2 Channels ring Aid G ph Channe ph Channe ph Channe	uidance al 1 al 2 al 3 al 4				



- Select the name of the questionnaire you want to print from the list of reports.
- 3. Print the report.

## Printing

Printing within the Avant Audiometer software is very simple.

File	Function	Ear	Output	Aud	
0	pen			l.	
Sa	ive				
C	ear Session	Data		ĺ	
Ex	port				
Pa	ige Setup				
Print Setup					
Print Preview					
Pr	int				
G	o Back		Ctrl-Back		
Ex	it		Alt-F4		

From the File menu, click one of the following options:

**Page Setup** – Allows you to set margin sizes and the default text header for your reports.

**Print Setup** – selects the printer you want the report to be sent to.

**Print Preview** – Shows you what your report will look like before you print it.

**Print** – Sends the report to the printer. This option opens the Windows Print dialog which allows the user to select any installed printer and modify the properties (quality, number of copies, etc.) for the print job.

# **Limited Warranty**

MedRx, Inc warrants this product to be free from defects in material and workmanship for one year from the time of purchase. If this system fails to perform as specified during this period, the purchaser is responsible for calling MedRx at (888) 392-1234 or (727) 584-9600. The company's representative will advise the owner to either return specific components or the entire system to:

#### MedRx, Inc. 1200 Starkey Road #105 Largo, FL 33771 USA

MedRx will repair or replace any defective devices, fully test the system and/or components and ship the system promptly back to the owner. There is no cost for the repair or return shipping, provided the system is one year old or less and has not been misused, abused or damaged. Such damage includes, but is not limited to, dropping, exposure to excessive heat greater than 100°F and water/liquid damage.

Repair or replacement of the system as provided under this warranty is the sole and exclusive remedy of the purchaser. MedRx shall not be liable for any consequential or incidental damages or for breach of any express or implied warranty. Except to the extent of applicable law, any implied warranty, merchantability or fitness of this product is limited to the duration of this warranty.

MedRx will, at its discretion, service and repair out of warranty products at the purchaser's request, charging for parts and labor as necessary.

The limited warranty is deemed void if software or hardware is installed on this product which is not pre-approved by MedRx, Inc. Approved software includes NOAH<sup>™</sup> and HIMSA approved hearing aid manufacturer programming modules for fitting hearing aids.

MedRx, Inc is not responsible for problems resulting from installation of unapproved software or hardware. In the event of unapproved software or hardware installed on the system causing a conflict, MedRx will service the product for a fee to be determined at the time of service.

Any extension of this warranty past the initial one-year warranty is subject to the following (where applicable).

- 1. A \$300 deductible per repair.
- 2. Extended warranty does not include cables, connectors or peripherals.
- 3. Extended warranty of the Video Otoscope covers optics only.